

SANUS

SYSTEMS

Natural Furniture Instructions

QC#

Step 1

Check to be sure that you have all parts listed below. If any parts are missing or damaged, contact Sanus Customer Service at (800)359-5520 or www.sanus.com.

PART		NFCFT	NFCKT	NFEDT
Decorative Face Bolts	a	24	12	12
Three Hole Plate	b	8	4	4
Glass Protectors (pads of 4)	c	2	1	1
Hex Key	d	1	1	1
Glass Mid Shelves		1	1	1
Glass Top Shelf		1	1	1
Wood Frame		2	2	2
Steel Cross Tubes		12	6	6

Step 2

Push the Decorative Face Bolts into the front of the first Wood Frame. Seat them by tapping them lightly with a rubber hammer or the handle of a screw driver. They do not need to be tapped in all the way; this will happen in step 3. Lay the frame face down on a soft surface so that the threads of the Face Bolts point up.

Step 3

Place a Three Hole Bracket over each set of 3 Decorative Face Bolts. Attach a Steel Cross Tube to each Decorative Face Bolt on one of the Frames. Tighten the Tubes firmly by hand.

Step 4

Place Three Hole Brackets between each set of steel cross tubes and the frame on this side as well. Attach the second Frame to the other end of the Tubes and tighten carefully with the Hex Key.

Step 5

Install the Glass Mid Shelves. Clear rubber Glass Protector pads are included. Place a Glass Protector on the top corner of each Wood Frame. Set the Top Glass in place.

