
SANUS®

VMD1

(6901-002123 < 01>)



INSTALLATION INSTRUCTIONS

Sanus

6436 City West Parkway Eden Prairie, MN 55344 USA

Customer Service

Americas: 800-359-5520 • 952-225-6013 • info@sanus.com

Europe, Middle East, and Africa: + 31 40 2324700 • europe.sanus@milestone.com

Asia Pacific: 86 755 8996 9226 • sanus.ap@milestone.com

DISCLAIMER

Milestone AV Technologies and its affiliated corporations and subsidiaries (collectively "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Milestone AV Technologies, a Duchossois Group Company. All rights reserved. Sanus is a division of Milestone. All other brand names or marks are used for identification purposes and are trademarks of their respective owners.



WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.


CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.

WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all components are properly assembled and installed using the instructions provided.

WARNING: Failure to provide adequate structural strength for this component can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the structure to which this component is attached can support five times the combined weight of all equipment. Reinforce the structure as required before installing the component. The wall to which the mount is being attached may have a maximum drywall thickness of 5/8" (1.6cm).

WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components located between the VMD1 Monitor Arm up to (and including) the display does not exceed 25 lbs (11.34 kg) per arm. Use with products heavier than the maximum weight indicated may result in collapse of the mount and its accessories causing possible injury.


DIMENSIONS




LEGEND

	Timbton Costonou	Densil Mark
	Tighten Fastener Apretar elemento de fijación	Pencil Mark Marcar con lápiz
G		
	Befestigungsteil festziehen Apertar fixador	Stiftmarkierung Marcar com lápis
	-	NY
	Serrare il fissaggio	Segno a matita
	Bevestiging vastdraaien	Potloodmerkteken
	Serrez les fixations	Marquage au crayon
\bigcirc	Loosen Fastener	Drill Hole
	Aflojar elemento de fijación	Perforar
	Befestigungsteil lösen	Bohrloch
	Desapertar fixador	Fazer furo
	Allentare il fissaggio	Praticare un foro
	Bevestiging losdraaien	Gat boren
	Desserrez les fixations	Percez un trou
	Phillips Screwdriver	Adjust
(Destornillador Phillips	Ajustar
	Kreuzschlitzschraubendreher	Einstellen
	Chave de fendas Phillips	Ajustar
	Cacciavite a stella	Regolare
	Kruiskopschroevendraaier	Afstellen
	Tournevis à pointe cruciforme	Ajuster
	Open-Ended Wrench	Remove
	Open Ended Wichen	
•	Llave de boca	Quitar
611		
W	Llave de boca	Quitar
OS O	Llave de boca Gabelschlüssel Chave de bocas	Quitar Entfernen Remover
O O	Llave de boca Gabelschlüssel	Quitar Entfernen Remover Rimuovere
0	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte	Quitar Entfernen Remover
68	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche	Quitar Entfernen Remover Rimuovere Verwijderen Retirez
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand	Quitar Entfernen Remover Rimuovere Verwijderen Retirez Optional
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano	Quitar Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand	Quitar Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Optional
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão	Quitar Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano	Quitar Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional Opcional Opcional Opcional Opcional Opcional
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand	Quitar Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional Opzionale Opzionale Optie
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand À la main	Quitar Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional Opcional Opcional Opcional En option
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand À la main Hex-Head Wrench	Quitar Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional Opcional Opcional Opcional En option Security Wrench
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand À la main Hex-Head Wrench Llave de cabeza hexagonal	Quitar Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional Opzionale Optie En option Security Wrench Llave de seguridad
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand À la main Hex-Head Wrench Llave de cabeza hexagonal Sechskantschlüssel	Quitar Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional Opzionale Optie En option Security Wrench Llave de seguridad Sicherheitsschlüssel
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand À la main Hex-Head Wrench Llave de cabeza hexagonal Sechskantschlüssel Chave de cabeça sextavada	Quitar Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional Opzionale Optie En option Security Wrench Llave de seguridad Sicherheitsschlüssel Chave de segurança
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand À la main Hex-Head Wrench Llave de cabeza hexagonal Sechskantschlüssel Chave de cabeça sextavada Chiave esagonale	Quitar Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Opcional Opzionale Opzionale Optie En option Security Wrench Llave de seguridad Sicherheitsschlüssel Chave de segurança Chiave di sicurezza
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand À la main Hex-Head Wrench Llave de cabeza hexagonal Sechskantschlüssel Chave de cabeça sextavada	Quitar Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional Opzionale Optie En option Security Wrench Llave de seguridad Sicherheitsschlüssel Chave de segurança

TOOLS REQUIRED FOR INSTALLATION



PARTS



Installation Instructions VMD1

Connecting VMD1 to Desk

1. Loosen clamp screw until enough space is created between clamp and mount to allow for desk mounting. (See Figure 1)

NOTE: If space is limited behind desk (i.e. against wall, etc.), remove clamp entirely in Step 1 and reattach clamp prior to Step 3!

- 2. Place mount on top of desk at desired mounting location. (See Figure 1)
- Tighten clamp using clamp screw until mount is securely fastened to desk. (See Figure 1)




Figure 1

Display Installation

 Remove quick release faceplate from mount by pressing quick release tab and sliding faceplate off mount. (See Figure 2)




Figure 2

WARNING: Only remove display from mount when the display can be lifted up from the mount! DO NOT remove display unless the display is in the upright position! See Display Removal section for details.

- 2. Carefully place display face down on protective surface.
- 3. Connect faceplate to display

For flush mounting hole installation:

 Using Phillips screwdriver, carefully install four M4x14mm screws (B) through corresponding holes on faceplate and into the mounting holes on the display. (See Figure 3)




Figure 3

For recessed mounting hole installation:

- Place four spacers (D) on top of mounting holes on back of display. (See Figure 9)
- Using Phillips screwdriver, carefully install four M4x25mm screws (C) through corresponding holes on faceplate, spacers (D) and into the mounting holes on the display. (See Figure 4)




Figure 4

- Position display with faceplate attached above mount. (See Figure 5)
- Slide faceplate onto mounting head until quick release tab clicks into place. (See Figure 5)




Figure 5

Installation Instructions VMD1

Adjustments

Head Tilt Adjustment

- 1. Adjust head tilt to desired tilt position. (See Figure 6)
- 2. Adjust head tilt tension screw to change the adjustment tension. (See Figure 6)

Height Adjustment



CAUTION: OVERTENSIONING THE HEIGHT-ADJUSTMENT TENSION SCREW MAY CAUSE DAMAGE! Do NOT overtighten height-adjustment tension screw when adjusting tension for lighter or heavier displays.

- Adjust arm height to desired level. (See Figure 6)
- Open cable management cover on upper arm to expose height-adjustment tension screw. See Cable Management section for details.
- 3. Use 1/8" hex key (F) to adjust height-adjustment tension screw to change adjustment tension. (See Figure 6)

NOTE: Turn clockwise to reduce tension for lighter displays and counter-clockwise to increase tension for heavier displays.

Pivot Adjustment

- 1. Adjust pivot position as desired. (See Figure 6)
- 2. Use 3/16" hex key (E) to adjust pivot point tension screws to change pivot adjustment tension. (See Figure 6)




Figure 6

Pivot Adjustment Range

 Adjust arm angle as desired up to 90 degrees in either direction. (See Figure 7)



WARNING: Swinging the arm beyond 90 degrees may result in the mount slipping off the desk causing serious injury!




Figure 7

Portrait Adjustment

 The monitor may be adjusted 90 degrees in either direction in order to provide a portrait view of the monitor. (See Figure 8)




Figure 8



WARNING: Only remove display from mount when the display can be lifted up from the mount! DO NOT remove display unless the display is in the upright position! See Display Removal section for details.

Cable Management

- 1. Use screwdriver to unhinge tab on either end of cable management cover on upper arm. (See Figure 9)
- Slide screwdriver along edge of cover until remaining tabs are unhinged and cover is in the "open" position. (See Figure 9)




Figure 9




Figure 10

3. Route cables through cable management channels. (See Figure 10)

IMPORTANT! Be sure to leave enough slack in the cables near display and arm joint to allow for full arm articulation!

- Close cable management covers on monitor arm. (See Figure 10)
- Repeat Steps 1-4 for lower arm.

Display Removal



WARNING: Only remove display from mount when the display can be lifted up from the mount! DO NOT remove display unless the display is in the upright position! (See Figure 11)

- 1. Make sure display is in the upright position.
- Remove quick release faceplate from mount by pressing quick release tab and sliding faceplate off mount. (See Figure 11)




Figure 11